






Fixture COLMEIA





NOT INCLUDED



1. Power supplies 24V 250W
2. Suspension base FI suspended
3. Fixtures GIZA-DUO-LL

Type of fixture	Dimensions (L x H x W)		
COLMEIA S	2000 x 3000 x 2000		
COLMEIA M	4000 x 3000 x 4000		
COLMEIA L	6000 x 3000 x 6000		

NOTE!



Make sure the ceiling has sufficient support capacity!

The method and type of anchoring the steel base to the existing ceiling is determined by the facility administrator at the installation site.

Make sure the power is turned off before you start any installation or maintenance work.

Installation is to be performed by qualified personnel with relevant permits and qualifications for connecting to and working on 230V AC and low-voltage networks.

Use a Laser Level to precisely mark the anchoring points. Define and mount the base using 4 mounting points (page 5).



Make sure cables are not damaged. In order to ensure full suspension, the steel cables have to be clean and free from greases, oils and rust. During installation, the nozzle of the pendant mounted on the fixture must have a discernible tension in the wire. Steel wires can only be used with the supplied fasteners!

Damaged cables and steel wires can only be replaced by the factory.

The wire ceiling bracket nut must be fully tightened to the suspension fastener.



The product is not suitable for outdoor use!

Any modification of the fixture will void any and all written or implied warranties.

The manufacturer accepts no responsibility for damage to persons or property arising through improper use or installation.

IP20 IP20 Covered





For indoor use only





Protection class I

220-240V






4



8

I




II





22 0-24 0V
AC 50/60Hz

III




IMPORTANT: The method and type of anchoring the steel base to the existing ceiling is determined by the facility administrator at the installation site.

IV




IMPORTANT: The method and type of anchoring the steel base to the existing ceiling is determined by the facility administrator at the installation site.


V




VI




VII




VIII





IX




X







XIII




XIV





XV




XVI



XVII




XVIII



13x

XIX



XX

