





**Parts needed to mount the 45-ZZ conductive head**




**Tools needed for mounting:**

- allen wrench

**NOTE!** A list of products corresponding with the selected accessories is available at [klusdesign.com](http://klusdesign.com).

**1.** Connect the power cable from an assembled lighting fixture to the power connector (C). Insert the lighting fixture into the mounting bracket (A).



**2.** Mount the arm in the head (D) by tightening the pressure screw in the head with the Allen wrench.



**3. NOTE!** The position of the lighting fixture on the arm can be adjusted in the range of 360° (depending on the distance of the fastener from the edge of the extrusion).

